

Mini Novelty Pocket RF Bug and Camera Detector



Summary

What a great little unit, simple to use and quite effective for a novelty unit. Simply press the button and search for bugs and hidden cameras

Instructions:

1. Pull up the antenna on the device.
2. Keep pressing the "A" button the light will illuminate, when moving about receiving radio waves, the sound ringing indicator light flashes at the same time it can be long-range (depending on the strength of transmission power) to launch the region lock.
3. Continue to press the "B" key to search for short-range signals, when it receives the radio waves, sound will emit and start ringing, the indicator light flashes at the same time.
4. When sustained by the "B" key to search for short-distance, if the distance is only 2M away it may be a result of power from large objects or interference, at this time it may be appropriate to shorten the antenna.
5. Battery replacement: Use 12V car battery remote control; open the panel to replace the screw.