



TIE CAMERA USER MANUAL



1. Power on/off 2. Camera 3. USB Port 4. LED 5. Remote Control

Operation

Switch on

Open the zip on the back of the tie, press the power switch to the "ON" position, the camera will go into power-saving mode.

Record video

1) Press the remote control key for several seconds, and the green light will blink for 2 seconds and then green light will turn off, indicating that the camera is recording video and audio.

2) Press the remote control once again, it will save data and the green light blinks once and then will turn off, the video is saved and the camera goes into standby mode.

Switch off

Under standby mode or power-saving mode, push the power to the “OFF” position, and the camera will turn off.

Attention: In order to save power, please turn off when the product is not in use.

Charging

Under power off mode, connect the camera via USB with the charger; the green light of the charger will turn on. The green light turns off when it is fully charged.

Playback

After recoding, switch on the camera, in standby mode, connect the camera to the computer via USB cable, then the files can be played on the computer. Before connecting please make sure the computer has installed the related playing software.

Setting Time

When using the device for the first time, you can set the time for the video as follows:

The first line: [date]

The second line: 2009/12/12

The third line: 12:12:12

Create new names “TAG” txt. File and then copy the file to the root of the disk of the camera. When starting the camera again next time, the time will be simultaneous as the time file.

Attention: Please keep power on when you set time; otherwise it will skip to the default time.

Attention

- 1) Please ensure battery is charged for a minimum of 4 hours before use.
- 2) When the device is running low in battery whilst taking video, the system will save the video data first and then shut down automatically.
- 3) When taking video continually, the system will automatically generate a new video file after each operation.
- 4) The device has built-in high-capacity polymer lithium battery, so it has a memory effect. We advise in the first 5 times of usage, charge the battery fully after the battery is out of use, so that the battery can work within its max working hours perfectly.

Technical Data

- 1) Functions: recording video and audio by Remote Control, USB drive
- 2) Video: AVI, 720*480 resolutions
- 3) Internal Memory: 2GB/4GB/8GB
- 4) USB: 2.0 (Hs)
- 5) Charging time: 4-5 hours

6) Battery use time: built-in Li battery, 1-2 hours

7) Operation systems: No need for driver installation if the operating system is Windows ME/ 2000/ XP/ VISTA or above (windows98 is excepted)